


# MODEL JB-600

## SINGLE LINE TELEPHONE



### OWNER'S GUIDE

Please read this instruction manual carefully

repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.

10. Unplug this product from the wall outlet and refer to qualified service personnel under the following conditions:
  - a. When the power supply cord or plug is damaged or frayed.
  - b. If liquid has been spilled into the product.
  - c. If the product has been exposed to rain or water.
  - d. If the product does not operate normally by following the operating instructions. Adjust only those controls, that are covered by the operating instructions because improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
  - e. If the product has been dropped or the cabinet has been damaged.
  - f. If the product exhibits a distinct change in performance.
11. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
12. Do not overload wall outlets and extension cords as this can result in the risk of fire or electrical shock.
13. Do not use the telephone to report a gas leak in the vicinity of the leak.

### SAVE THESE INSTRUCTIONS

### C Features

Congratulations on your purchase of the JB-600 single line telephone.

- Flash button.
- Adjustable Receive volume level.
- Last Number Redial
- Tone/Pulse Dialing select switch.
- On/Off Ringer select switch.
- Visual Incoming Call Indicator
- Mute button.
- Fully modular Cords
- Desk or Wall mountable

### D Installation

#### Connecting to the telephone line

1. Select a location for the telephone that is within seven (7) feet of an existing telephone jack.
2. Plug one end of the supplied handset coiled cord into the handset modular jack. Plug the remaining end into the modular handset jack located on the side of the telephone base.
3. Connect the end of the supplied telephone line cord into the telephone line modular jack located on the bottom surface of the base. Connect the remaining end of the cord into an existing telephone wall jack.
4. Place the handset into the telephone base.

### A Important Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electrical shock, and injury to persons including the following:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners, or aerosol cleaners. Use a damp cloth for cleaning. If necessary, use a mild soap.
4. Do not use this product near water, for example near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.
5. Do not place this product on an unstable cart, stand or table. The product may fall, causing serious damage to the product.
6. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
7. Do not allow anything to rest on the telephone line cord. Do not locate this product where the cord will be abused by persons walking on it.
8. Never push objects of any kind into this product through the cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
9. To reduce the risk of electric shock, do not disassemble this product, but take it to a qualified serviceman when some service or

### B FCC Requirements

This equipment is registered with the Federal Communications Commission and is in compliance with Part 68 of the FCC Rules and Regulations.

On the bottom of this equipment is a label indicating among other information, the FCC Registration Number and Ringer Equivalence Number (REN) for this equipment. Upon request, you must provide this information to your telephone company. The REN is useful to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5).

- The JB-600 telephone cannot be used on coin service pay telephones.
- The JB-600 telephone cannot be connected to party lines.
- The JB-600 telephone is Hearing Aid Compatible

If you experience trouble with this telephone equipment, disconnect it from the telephone network until the problem has been corrected. The telephone company may discontinue service if your telephone equipment causes harm to the telephone network. In this case, the telephone company will:

- Notify the customer that service is being discontinued.
- Provide the customer with the opportunity to correct the situation.
- Inform the customer of their right to file a complaint with the FCC.

### Wall Mounting

The JB-600 can be mounted to most walls using two self-tapping screws and plastic expansion anchors (not supplied). Choose a mounting location for the telephone that is near an existing modular type telephone jack. Follow the above instructions but with the following additions.

Carefully press the telephone line cord into the recessed groove located on the bottom surface of the telephone base. Make sure that the cord is flush with the back surface. Locate pilot holes for two self tapping screws at a distance 10 cm from each other and located on a vertical center line.

If you are mounting the telephone to a plaster board wall surface, it may be necessary to first drill two  $\frac{3}{16}$  inch pilot holes to install two expanding plastic anchors (not supplied) into the wall.

Press a plastic anchor into each of the two holes. Use a hammer to lightly tap the anchor into the wall until the anchor is completely seated. Insert a screw into each anchor and tighten each screw with a screwdriver. Tighten each screw just enough to allow the keyhole shaped holes in the rear of the base enough clearance to slip snugly over each screw head.

Place the telephone handset into the cradle

### E Operation


#### Setting the T/P dialing switch

Your JB-600 telephone can operate in tone or pulse dialing mode.

1. Set the T/P switch located on the handset to the desired position.

2. If you're not sure which service you have, set the **T/P** switch to the **T** position.
3. Lift the handset and dial your number.
4. If dial tone continues, you have pulse dialing service, set the **T/P** switch to the **P** position.

#### Control Locations



#### Receiving Calls

To receive a telephone call, pick up the handset when the telephone rings.

1. The visual incoming call indicator will flash during ringing. Hang up the handset by placing it face down in base when you finish your call.

#### Making Calls

To make a telephone call, pick up the handset from the base. When you hear dial tone, dial the desired number. Hang up when you finish your call by putting the handset face down in the base.

#### Using the Flash button

Press the **FLASH** button momentarily to get a new dial tone to make another call without hanging up the handset. If you are a subscriber, the **FLASH** button can also be used to access special telephone company features such as call waiting.

1. Press the **FLASH** button located on the telephone handset to put the existing call on hold and answer the new call. When you finish the call, press the **FLASH** button to return to the original call.

#### Using the Redial button

To redial the last number dialed, pick up the handset and momentarily depress the **REDIAL** button after dial tone is heard. 32 is the maximum number of digits that can be redialed.

#### Using the Mute button

Press and hold the **MUTE** button to prevent the other party from hearing conversations you are having at your end of the line. To resume normal operation, release the **MUTE** button.

#### G Limited Warranty

A. TT Systems LLC warrants that the JB-600 sold by TT Systems LLC within the continental limits of the United States, Hawaii and Alaska, are free from defects in materials and workmanship under normal use and service for 90 days. This warranty is applicable only to the original purchaser of the JB-600, when accompanied by a sales receipt stating the date of purchase and name of the company from which purchased. This warranty is in lieu of and excludes all other warranties, expressed or implied, including any implied warranty of merchantability or fitness, and of any other obligation on the part of TT Systems LLC.

B. If the JB-600 shall prove to be defective, then TT Systems LLC shall either replace or repair the JB-600 at its discretion as follows:

1. At no cost to the original purchaser except shipping charges, within 90 days of the date of purchase.
2. Warranty service for your JB-600 is provided by TT Systems LLC. Within 90 days of purchase, you may return the JB-600 to TT Systems LLC at the following address:

**TT Systems LLC LLC**  
**4 Executive Odell Plaza**  
**Yonkers, New York 10701**  
**Tel: 914-968-2100**

C. Shipping charges are at the customer's

#### Setting the Receive HI/LO switch


Set the **Receive HI/LO** switch to the **LO** position to normal receive volume level. Set the **Receive HI/LO** switch to the **HI** position for maximum receiver volume level.

#### Setting the RINGER ON/OFF switch

Set the **RINGER** switch located on the bottom surface of the telephone base to the **ON** position to turn on the ringer sound.

1. Set the ringer **RINGER** switch to the **OFF** position to turn off the ringer sound.

#### Bottom of Base View



#### F Care and Maintenance

Your JB-600 telephone has been designed to give trouble free service. Please read the following maintenance instructions.

1. Keep away your telephone from heat, high temperatures can shorten the life of the electrical components as well as distort or melt plastic parts.
2. Keep your telephone free of dust and moisture. If it gets wet, wipe it dry immediately. Liquids can contain minerals that can corrode electronic circuits.
3. Handle your telephone gently. Dropping it can cause serious damage to the circuitry, or the plastic case, which may result in causing it to malfunction.
4. Do not use any type of chemical or any abrasive powder to clean the cabinet. Use only mild detergents on a soft, damp cloth.
5. In the case of trouble, do not attempt to repair the telephone yourself. It is the responsibility of users requiring service to report the need for service to our Service Department. They will make the necessary arrangements for repair or replacement.
6. If you should have any questions about the operation of your JB-600 telephone, please call our Service Department at **1-800-276-5844**, between the hours of **9:00 A.M.** and **9:00 P.M.** Eastern time **Monday - Friday**. Or you may contact TT Systems LLC for technical assistance via our Internet Website: **www.tech@ttsystems.com** or via e-mail at **tech@ttsystems.com**.

expense. Please include a copy of your sales receipt and a check or money order made out to TT Systems LLC for the amount of \$7.50 to cover shipping and handling.

- D. There is no informal dispute settlement mechanism available.
- E. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you.
- F. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.
- G. This warranty does not extend to any JB-600 sold by TT Systems LLC which has been subjected to misuse, neglect, accident, improper application, improper installation or to use in violation of the instructions furnished by TT Systems LLC. This warranty does not extend to or apply to any JB-600 which has been repaired or altered by any persons who have not been expressly approved by TT Systems LLC.
- H. TT Systems LLC shall not be liable for any special or consequential damages or for loss or expense directly or indirectly arising from use of the products or any inability to use them either separately or in combination with other equipment or product accessories or from any other cause.
- I. TT Systems LLC reserves the right to make changes in the design of the JB-600 and to make additions or improvements to the JB-600 without incurring any obligation to modify any JB-600 previously sold.